

## EXOTIC WEVE TILES INTALLATION



### STEP 1:

USE NAIL, GLUE OR DRYWALL SCREWS TO FASTEN TILES.

### STEP 2:

INTERLOCK OTHER TILES COVERING THE SCREWS

NAIL HERE—  
next tile hides tab

