

## SLATWALL TEXTURE PANELS INSTALLATION TIPS

### Tools:

- Screwdriver
- Screws
- 2' x 8' Textured Panels
- Slatwall accessories after it is installed

To minimize the joints typically start at the bottom with one full sheet then the next panel on top of that cut a half sheet so the joints are staggered and continue with full sheets to complete the project. This will minimize the joints.

To attach the panels to the wall put screws to secure panels through the inserts into the studs behind the wall to give strength and lessen the visibility of the screws. Also, be sure to put the painted metal inserts in between each panel so there are no horizontal joints.

